


**AKAI**  
*professional*

**MX73**

**MIDI MASTER KEYBOARD**



**WARNING**

To prevent fire or shock hazard, do not expose this appliance to rain or moisture.

**Operator's Manual**

# Warning

## Power requirements

Power requirements for electrical equipment differ from area to area. The operating voltage of this machine is preset at the factory according to its intended destination. However, some models are equipped with a voltage selector. If your machine is so equipped, before connecting, check to see that the VOLTAGE SELECTOR on the bottom panel is set to the voltage for your area.

If not, please set it correctly before plugging in the power cord.

220 V, 50 Hz for Europe except the UK.


240 V, 50 Hz for UK and Australia.

120 V, 60 Hz for USA and Canada.

## If the VOLTAGE SELECTOR is not set for your area:

Confirm that the power cord is disconnected.

Move the VOLTAGE SELECTOR with a screwdriver so that the marker is above the voltage for your area.



## What you should know to protect yourself and the Akai MX73.

Watch out! You might get an electric shock.

- Never touch the plug with wet hands.
- Always pull out by the plug and never the cord.
- Let a qualified professional repair or reassemble the Akai MX73. An unauthorized person might touch the internal parts and receive a serious electric shock.
- Never allow a child to put anything, especially metal, into the Akai MX73.

Let's protect the Akai MX73 too.

- Use only a household AC power source. Never use a DC power source.
- If water is spilled on the Akai MX73, disconnect it and call your dealer.
- Make sure that the AKai MX73 is well ventilated and away from direct sunlight.
- To avoid damage to the internal circuits and the external surface, keep away from heat (stoves, etc.).
- Avoid using spray type insecticide near the Akai MX73. It can damage the finish and might ignite suddenly.
- To avoid damaging the finish, never use denaturated alcohol, paint thinner or other similar chemicals to clean the Akai MX73.
- Place the Akai MX73 on the flat and solid surface.

To enjoy the Akai MX73 for a long time, please read this operator's manual thoroughly.

Should a problem persist, write down the model and serial numbers and all pertinent data regarding warranty coverage as well as a clear description of the existing trouble. Then, contact your nearest authorized Akai Service Station, or the Service Department of Akai Electric Company, Tokyo, Japan.

# Precautions

## FOR CUSTOMERS IN THE UK

### IMPORTANT FOR YOUR SAFETY

The flex supplied with your machine will have two wires as shown in the illustration.

### TWO CORE FLEX IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:



Blue: Neutral

Brown: Live

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows: The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

- Do not connect any wire to the larger ptm marked E or  $\perp$  when wiring a plug. Ensure that all terminals are securely tightened & that no loose strands of wire exist.



The lightning flash with the arrowhead symbol superimposed across a graphical representation of a person, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure, that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

# Features

1. The MX73 can be used as a MIDI master control keyboard for control of all MIDI functions.
2. There are a total of 100 program memories (00–99), and four areas (I–IV) for each program.
3. Each parameter can be preset for the four MIDI output systems (areas I-IV).
4. MIDI messages DO-34 (control change) can be set freely by four control sliders, and messages 64-95 can be set by four control switches (ON/OFF).
5. A key velocity function makes it possible to create of a natural touch response.

**NOTE:** The MX73 unit does not include a sound source. Use it in connection with other MIDI-compatible instruments.

# Table of Contents

|                                       |    |
|---------------------------------------|----|
| Warning..                             | 1  |
| Precautions .....                     | 1  |
| Features .....                        | 2  |
| Specifications .....                  | 2  |
| Controls..                            | 3  |
| Operating Procedures .....            | 5  |
| Programming.....                      | 7  |
| Operations .....                      | 12 |
| Example of Programming Patterns ..... | 14 |
| Tape Interface .....                  | 17 |
| MIDI Implementation chart .....       | 18 |


# Specifications

|                             |                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|-----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Keyboard:</b>            | 73-key 6-octave C scale                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Internal Memory:</b>     | 1 00 programs                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>External Memory:</b>     | Cassette interface                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Functions:</b>           | Master level<br>TUNE request <b>ON/OFF</b><br>Key transpose<br>Programmable control<br>Changevolumes x4<br>Programmable control<br>change switches x4<br>Programmable parameters<br>Wheel<br>Bend<br>MIDI Channel<br>Program number<br>Split point<br>Octave shift<br><b>POLY/MONO</b><br><b>OMNI ON/OFF</b><br>Control select<br>Control switch <b>select</b><br>Control number set<br>Switch number set<br>Sustain <b>ON/OFF</b> |
| <b>External Jacks:</b>      | MIDI OUT x2<br>EXT OUT x 1<br>TAPE (IN/LOAD. OUT/SAVE)<br>PROGRAM UP<br>SUSTAIN PEDAL<br>CONTROL (1–4): For foot <b>switch</b><br>CONTROL (1–4): For foot control<br>LC display                                                                                                                                                                                                                                                    |
| <b>Display:</b>             | LC display                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>External Dimensions:</b> | 1,152 (W) × 110 (H) × 364 (D) mm                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Weight:</b>              | 13kg                                                                                                                                                                                                                                                                                                                                                                                                                               |


For improvement purposes, specifications and design are subject to change **without notice**.

# Controls

## CONTROL PANEL



## OUTLINE DIAGRAM




**REAR PANEL**

**POWER Switch**  
Use this switch to turn the MX73 power on and off.

**CONTRAST Control**  
Use this control to adjust the contrast of the display.

**PEDAL SWITCH Jacks**  
Use these jacks to operate the control switches using the foot switch



**MIDI OUT Jacks**  
These are output jacks for transmitting MIDI signals processed by the MX73 to a synthesizer, sampler, etc.

**TAPE IN/OUT Jacks**  
Use these jacks to store memory data set in the MX73 on a cassette tape or to recall the data from a cassette tape.



**PEDAL CONTROL Jacks**  
Use these jacks to control the CONTROL volume using the foot switch.

**EXT OUT Jack**  
Use this jack to transmit only program number changes (MIDI messages).

**PROGRAM UP Jack**  
Use this jack to switch the program using the foot switch.

**SUSTAIN Jack**  
Use this jack to switch the sustain data using the foot switch.


**EXAMPLE OF CONNECTIONS**



# 5

## Operating Procedures

In order to properly comprehend the MX73, we suggest you set the parameters as shown below, checking the display at each step.



1. Turn the POWER switch ON.  
"PLAY PROGRAM: 00" will appear on the display.
2. Next press the EDIT button. The indicator will light. "I: MIDI CH. 01" will appear on the display and the MIDI channel can be verified.
3. Press the FWD/LOAD button. The display will change as shown below each time the button is pressed.

PLAY PROGRAM: 00

I: MIDI CH. 01

- Check the split point.

I: SPLIT 1C ↔ 7C

- Check the octave shift.

I: OCTAVE SHIFT 0

- ~~Check~~ the program number.

I: PROGRAM NO. 00

- Check whether pitch bend is ON or OFF.

I: BEND ON

- Check whether the modulation wheel is ON or OFF.

I: WHEEL ON

- Check whether in the MIDI POLY or MONO mode.

I: POLY MODE

- Check whether **MIDI OMNI** is ON or OFF.
- Check **the velocity level**.
- Check whether the control switches are ON or OFF
- Check whether the control volumes are ON or OFF.
- Check the control switch numbers, and value.
- Check the control volume numbers, and value.
- Check the sustain pedal data.

|                     |      |
|---------------------|------|
| I:OMNI              | OFF  |
| I:VELOCITY          | 18   |
| I:CONTROL SW        | ---- |
| I:CONTROL UL        | ---- |
| CONTROL SW-1        | 64   |
| CONTROL UL-1        |      |
| SUSTAIN I II III IV |      |

**MX73 STATUS CHART**


| Parameter            | Value          |
|----------------------|----------------|
| MIDI CH.             | 1-16           |
| SPLIT POINT          | 1C~7C          |
| OCTAVE SHIFT         | -3~+3          |
| PROGRAM NUMBER       | 0-127          |
| BEND SELECT          | ON/OFF         |
| WHEEL SELECT         | ON/OFF         |
| POLY/MONO SELECT     | POLY/MONO 0~15 |
| OMNI ON/Off          | ON/OFF         |
| CONTROL SW. SELECT   | ON/OFF         |
| CONTROL VOL. SELECT  | ON/OFF         |
| SW. No. SET          | 64~95          |
| VOL. No. SET         | 0-31           |
| KEY VELOCITY         | 1-10           |
| SUSTAIN PEDAL SELECT | I-IV           |

Areas I through IV can **each** be set independently.

Same **for** areas I through IV.

# Programming

- Press the EDIT button to set the MX73 to the edit mode. (The indicator will light.)
- Use the SELECT buttons (7, 4, 1 and 0) to select the area. (I~IV)



## MIDI CHANNEL SETTING

1. Press the FWD/LOAD or BWD/VERIFY button to set to the MIDI CH display.
2. Press the UP or DOWN button to select the desired MIDI channel.

I:MIDI CH.01

I:MIDI CH.05

## SPLIT POINT SETTING

1. Press the FWD/LOAD button to set to the SPLIT display.
2. Press the DOWN button to set to the lower voice setting mode. The cursor will appear on the display.
3. Press the desired key. The cursor will disappear and the number of the pressed key will be displayed.
4. Press the UP button to set to the upper voice setting mode. The cursor will appear on the display.
6. Press the desired key. The cursor will disappear and the number of the pressed key will be displayed.

I:SPLIT 1C↔7C |

I:SPLIT 1C↔7C

I:SPLIT 1C↔7C

I:SPLIT 1C↔7C

IWLIT 1C↔3C

- Split points can be set for each of Areas I~IV, so the keyboard can be split in four sections. Split points can also be set to overlap.



## OCTAVE SHIFT SETTING

1. Press the FWD/LOAD button to set to the OCTAVE SHIFT display.
2. Press the UP or DOWN button to set to the **desired** octave value (-3 to +3).

I:OCTAV SHIFT 0 ,

I:OCTAV SHIFT +1

## PROGRAM NUMBER SETTING

1. Press the FWD/LOAD button to set to the PROGRAM NO. display.
2. Press the UP or DOWN button to set the program number (0 to 127).
  - The program number on the MX73 is **compatible** with the program number on the slave **side**. Depending on the **equipment**, however, the actual **program** number may be different.

I:PROGRAM NO. 00

I:PROGRAM NO.127

## PITCH BEND SETTING

1. Press the FWD/LOAD button to set to the BEND display.
2. Press the UP (ON) or DOWN (OFF) button to **set** the **pitch bend ON or OFF**.
  - The amount of bend is **adjusted** on the **stave side**.

I:BEND ON

I:BEND OFF

## WHEEL SETTING

1. Press the FWD/LOAD button to **set** to the WHEEL display.

I:WHEEL ON

I: WHEEL OFF

Press the UP (ON) or DOWN (OFF) button to **set** the **modulation wheel ON or OFF**.

- Adjust the **modulation wheel** on the **slave side**.

**POLY/MONO SETTING**

The MIDI mode on the slave side can be set to either POLY or MONO.

1. Press the FWD/LOAD button to set to the POLY MODE display.
2. Press the UP (POLY) or DOWN (MONO) button to set the MIDI MODE.

|        |      |
|--------|------|
| I:POLY | MODE |
|--------|------|

|        |         |
|--------|---------|
| I:MONO | MODE 00 |
|--------|---------|

**OMNI SETTING**

The MIDI mode on the slave side can be set to either OMNI ON or OMNI OFF.

1. Press the FWD/LOAD button to set to the OMNI display.
2. Press the UP (ON) or DOWN (OFF) button to set the MIDI MODE.

|        |     |
|--------|-----|
| I:OMNI | OFF |
|--------|-----|

|        |    |
|--------|----|
| I:OMNI | ON |
|--------|----|

**KEY VELOCITY SETTING**

This sets the strength of the MX73 key velocity. There are 10 possible steps, from 1 for no velocity to 10 for maximum strength velocity.

1. Press the FWD/LOAD button to set to the VELOCITY display.
  2. Press the UP (ON) or DOWN (OFF) button to set the VELOCITY strength.
- This is only possible if the velocity function is provided on the slave equipment.

|            |    |
|------------|----|
| I:VELOCITY | 10 |
|------------|----|

|            |   |
|------------|---|
| I:VELOCITY | 8 |
|------------|---|

## CONTROLLERS

- There are two types of controllers: control volumes and control switches.
- The control volumes (1-4) are of the continuous variable type. One MIDI message (control change) from 0 to 31 can be set for each control slider. The aet effect becomes stronger as the slider is moved up.
- The control switches (1-4) are of the ON/OFF type. When ON, the LED lights. One MIDI message (control change) from 64-95 can be set for each control switch. These eight programmable controllers can be used while performing for real time operation.

## CONTROL SWITCH SELECTION

1. Press the FWD/LOAD button to aet to the CONTROL SW display.
2. Press the control switches (1-4) to turn them ON or OFF. (When ON, the switch number is displayed.)

I:CONTROL SW ----

I:CONTROL SW 1234

## CONTROL VOLUME SELECTION

1. Press the FWD/LOAD button to set to the CONTROL VL display.
2. Press the control switches (1-4) to turn the volume ON or OFF. (When ON, the switch number is displayed.)

I:CONTROL VL----

I:CONTROL VL1234

## CONTROL SWITCH PRESETTING

1. Press the FWD/LOAD button to aet to the CONTROL SW-1 64 display.
2. Press the control switches (1-4) to be used.
3. Press the UP or DOWN button to aet the MIDI message (64 to 95).

CONTROL SW-1 64

CONTROL SW-3 64

CONTROL SW-3 70

**CONTROL VOLUME PRESETTING**

1. Press the FWD/LOAD button to set to the CONTROL VL-1 01 display.
2. Press the control switches (1–4) to be used
3. Press the UP or DOWN button to set the MIDI message (00 to 31).

CONTROL UL-1 01

CONTROL UL-3 01

CONTROL UL-3 10

**SUSTAIN PEDAL SELECTION**

1. Press the FWD/LOAD button to set to the SUSTAIN display.
2. Press the control switches (1–4) to select the area (I–IV) for which the sustain pedal is to be used.

SUSTAIN - - - -

SUSTAIN I II--

**PARAMETER MEMORY SETTING**

The parameters for program numbers 00 to 99 can be stored in the memory.

1. Press the EDIT button to set to the edit mode. (The LED will light.)
2. Press the WRITE button to set to the WRITE PROGRAM -- display.
3. With the WRITE button depressed, press the BANK button and use the SELECT buttons to set the program number (00 to 99) to be stored in the memory.
  - Using the above procedure, set the parameters for each area and store them in the memory. Use the procedure explained below to recall a program in the memory.

WRITE PROGRAM --

WRITE PROGRAM 12

# Operations

## PROGRAM SELECTION

Use the following procedure to recall a program in the memory:

1. Press the BANK button. (The LED will light.)
2. Use the SELECT buttons to select the desired program number. (00 to 99)


3. When the program number is selected, the number of the selected program will appear on the display as follows: PLAY PROGRAM: 12

It is now possible to perform using the parameters set in the memory for program number 12.

When the control switches (1-4) set by the parameter are pressed at this time, the sustain data for the connected sound source can be controlled using the foot switch.

Also, the control sliders (1-4) set by the parameter can be used to control the modulation, portamento, etc.

NOTE: Avoid operating the modulation control or master volume after setting the control sliders.



PLAY PROGRAM: 12

## CHANGING THE MIDI CHANNEL

1. When the MIDI CH button is pressed, the MIDI channel for each area is displayed.

| Area I           | Area II | Area III | Area IV |
|------------------|---------|----------|---------|
| 01               | 06      | 16       | 86      |
| 81               | 86      | 16       | 86      |
| 01               | 06      | 89       | 06      |
| 01               | 86      | --       | 86      |
| E X T PROGRAM 12 |         |          |         |

2. With the MIDI CH button depressed, press the FWD or BWD button to move the cursor to the area to be changed.

3. With the MIDI CH button depressed, press the UP or DOWN button to change the MIDI channel.

- An area (I to IV) can be turned OFF by setting the MIDI channel display to "--".

NOTE: The changed data is cancelled when the power is turned OFF or program select button is pressed. Use the WRITE button to store the changed data in the memory.

## EXT CONTROL Operation

- When the EXT CONTROL button is pressed, the number of the program currently playing is displayed. (The LED will light.)

2. Press the BANK button, then use the SELECT buttons to set the program number (00–99).

3. The data for this program number is transmitted once only from the EXT OUT jack.

NOTE: When the EXT CONTROL button is released, the EXT OUT jack can be used for the normal MIDI OUT operation. This program number is not stored in the memory.

EXT PROGRAM --

EXT PROGRAM 16

### CHANGING THE PROGRAM NUMBER

1. When the MIDI PROGRAM NUMBER button is pressed, the program number (1 – 127) for each area is displayed.

01 62 46 127

2. With the MIDI PROGRAM NUMBER button depressed, press the FWD or BWD button to move the cursor to the area to be changed.

01 62 46 127

3. With the MIDI PROGRAM NUMBER button depressed, press the UP or DOWN button to change the program number.

01 62 46 95

### KEY TRANS BUTTON

1. A key is transposed by depressing the KEY TRANS button and pressing the desired key. (The LED will light.)

TRANSPOSE -D#

2. When the KEY TRANS button is pressed again, the LED will turn off and the key will no longer be transposed.

- The range for transposing is 2C# – 3C – 3B with 3C at the center.


### TUNE BUTTON

As there is no sound source in the MX73, pressing the, TUNE button transmits a tune request message to the slave side. When the TUNE button is depressed, "TUNE REQUEST" is displayed and all the connected MIDI sound sources are tuned.

NOTE: The TUNE function only operates when the equipment on the slave side is equipped with a tune request function.

<TUNE REQUEST>

# Example of Programming Patterns



## Splitting Keyboard Into 4 Sound Sources

Example

1. Use Area I for the harmony, Area II for the melody, and Areas III and IV for effects.

- I → Electric Piano      II -Flute
- III -Wind                  IV -Orchestra

Example


2. Set each area to a percussion instrument and use the keyboard as a rhythm box.

- I -Tam-tams              II -snares
- III -Chimes              IV → Handclaps

Example

3. This method can also be used to check the tuning, volume, or tone of the different instruments.

|                     | Area I<br>VX90     | Area II<br>AX60  | Area III<br>Ax73 | Area IV<br>S612  |
|---------------------|--------------------|------------------|------------------|------------------|
| MIDI CH.            | 1                  | 2                | 3                | 4                |
| SPLIT POINT         | 1C ↔ 2B            | 3C ↔ 4B          | 5C ↔ 5B          | 6C ↔ 7C          |
| OCTAVE SHIFT        | +1                 | 0                | +1               | - 2              |
| PROGRAM NUMBER      |                    |                  |                  |                  |
| BEND SELECT         | OFF                | ON               | OFF              | OFF              |
| WHEEL SELECT        | OFF                | ON               | OFF              | OFF              |
| POLY/MONO SELECT    | POLY               | POLY             | MONO             | MONO             |
| OMNI ON/OFF         | OFF                | OFF              | OFF              | OFF              |
| CONTROL SW. SELECT  | 1 ---              | 1 ---            | 1 ---            | 1 ---            |
| CONTROL VOL. SELECT | 12--               | 12--             | 12--             | 1 ---            |
| SW. NO. SET         | SW-1 64            | SW-1 64          | SW-1 64          | SW-1 64          |
| VOL. No. SET        | VL-1 01<br>VL-2 07 | VL-101<br>VL-207 | VL-101<br>VL-207 | VL-101<br>VL-207 |
| KEY VELOCITY        | 3                  | 10               | 10               | 10               |
| (S T A I N PEDAL    | ON                 | ON               | OFF              | OFF              |



## Splitting Keyboard Into 2 and Using for 4 Sound Sources

In this method, two sound sources can be mixed to form a voice, providing rich possibilities for expression.

Areas I and II: Harmony

Areas III and IV: Melody

Of

Areas I and II: Base

Areas III and IV: Harmony


Many other patterns can also be used.

|                | VX90               | AX60               | S900               | S612               |
|----------------|--------------------|--------------------|--------------------|--------------------|
| MIDI CH.       | 1                  | 2                  | 3                  | 4                  |
| SPLIT POINT    | 1C ↔ 2B            | 1C ↔ 2B            | 3c ↔ 7C            | 3c ↔ 7C            |
| OCTAVE         | +1                 | 0                  | +1                 | - 2                |
| PROGRAM NUMBER | -                  | -                  | -                  | -                  |
| BEND SELECT    | OFF                | OFF                | ON                 | ON                 |
| WHEEL          | ON                 | ON                 | ON                 | ON                 |
| POLY/MONO      | POLY               | POLY               | POLY               | POLY               |
| OMNI ON/OFF    | OFF                | OFF                | OFF                | OFF                |
| CON SW. SEL.   | 1...               | 1...               | 1...               | 1...               |
| CON VOL. SEL.  | 12--               | 12--               | 12--               | 12--               |
| SW. NO. SEL.   | SW-1 64            | SW-1 64            | SW-1 64            | SW-1 64            |
| VOL. NO. SEL.  | VL-1 01<br>VL-2 07 | VL-1 01<br>VL-2 07 | VL-1 01<br>VL-2 07 | VL-1 01<br>VL-2 07 |
| KEY VEL.       | 3                  | 10                 | 10                 | 10                 |
| SUSTAIN PEDAL  | ON                 | ON                 | OFF                | OFF                |



**Splitting Keyboard Into 2, Using 3 sound Sources in the Same Areas**

- Three sound sources can be used to create complex voices. As the range is wide, this method is especially suited for piano sounds. This method is also effective with strings, brass, and voice sounds. An ensemble effect can be obtained by slightly off-setting the three pitches.
- Use Area IV for special sound effects, animal noises for example.



|               | VX90              | Ax60             | S900               | S612              |
|---------------|-------------------|------------------|--------------------|-------------------|
| MIDI CH.      | 1                 | 2                | 3                  | 4                 |
| SPLIT POINT   | 1C → 5B           | 1C → 5B          | 1C → 5B            | 6C → 7C           |
| OCTAVE        | +1                | 0                | +1                 | -2                |
| PROGRAM NO.   |                   |                  | -                  |                   |
| BEND SEL.     | ON                | ON               | ON                 | OFF               |
| WHEEL         | ON                | ON               | ON                 | OFF               |
| POLY/MONO     | POLY              | POLY             | POLY               | POLY              |
| OMNI ON/OFF   | OFF               | OFF              | OFF                | OFF               |
| CON SW. SEL.  | 1 ...             | 1 ...            | 1 ...              | 1 ...             |
| CON VOL. SEL. | 12--              | 12--             | 12--               | 12--              |
| SW. NO. BEL.  | SW-1 64           | SW-1 64          | SW-1 64            | SW-1 64           |
| VOL. No. BEL. | VL-101<br>VL-2 07 | VL-101<br>M-2 07 | VL-1 01<br>VL-2 07 | VL-101<br>VL-2 07 |
| KEY VEL.      | 3                 | 10               | 10                 | 10                |
| SUSTAIN PEDAL | ON                | ON               | ON                 | ON                |

# Tape Interface

## SAVE/VERIFY/LOAD

The MX73 is equipped with an input and output jack and tape interface functions making it possible to store the parameters set in the program memory on a cassette tape. The tape interface functions include the save mode for outputting the program parameters and recording them on a cassette tape, the verify mode for checking whether the parameters recorded on the tape are correct, and the load mode for resetting the parameters recorded on the tape back onto the MX73.

The programs can be saved, verified, or loaded either one bank at a time or all at once (0 to 99).

- It is advisable to use the same cassette tape and recorder for both recording and playback.
- Do not subject the cassette recorder to shock or vibration when saving or loading, as this will make it impossible to save or load the parameters correctly.
- It is advisable to save two copies of the same parameters (one for backup) in case for some reason one is destroyed.
- It is not advisable to copy the parameters from one tape recorder onto another, as it is sometimes not possible to make correct copies.

## CONNECTIONS

Connect a cassette recorder to the MX73 TAPE IN/OUT jacks.

## PROCEDURE

- Saving (Verifying, Loading)
1. Set the connected tape recorder to the record mode (Playback mode for Verifying and Loading).
  2. Press the TAPE button. (The LED will light.)

TAPE:SELECT S,V,L

3. Press the SAVE (VERIFY, LOAD) button. "TAPE: SAVE ALL" will appear on the display, indicating that it is possible to save all the programs.

TAPE:SAVE ALL

4. To save only one bank, press the UP or DOWN button to select the bank number.

TAPE:SAVE 9

5. Press the SAVE (VERIFY, LOAD) button. "TAPE: SAV START" will appear on the display, and counting will start after several seconds.

TAPE:SAVE START

6. "SAVE END" will appear on the display when all the data has been saved. (In the verify mode, "GOOD" will be displayed.)

TAPE:SAVE END

If there is an error in the verify mode, change the tape recorder's output level and perform the verify operation several times. If there is still an error, change the tape and save the voice data. Also fill in the data for the parameters on a data sheet. If data is for some reason destroyed, use this follow sheet and reset the same voice data.

[ MIDI Master **KeyBoard** 1  
 Model **MX - 73** MIDI Implementation Chart Version :1.0

| Function . . .                                                            | Transmitted                                                                                                                                       | Recognized                      | Remarks                                                                                                       |
|---------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|---------------------------------------------------------------------------------------------------------------|
| Basic Default<br>Channel Changed                                          | 1 - 16<br>1 - 16                                                                                                                                  | ×<br>×                          | • memorized                                                                                                   |
| Mode Default<br>Messages' Altered                                         | MODE 1.2.3.4<br>OMNI ON/OFF M.P<br>*****                                                                                                          | ×<br>×<br>×                     | memorized                                                                                                     |
| Note Number : True voice                                                  | 00 - 120<br>*****                                                                                                                                 | ×<br>×                          |                                                                                                               |
| Velocity Note ON<br>Note OFF                                              | 9nH V=1-127<br>9nH V=0 ,8nH                                                                                                                       | ×<br>×                          |                                                                                                               |
| After Key's<br>Touch Ch's                                                 | ×<br>×                                                                                                                                            | ×<br>×                          |                                                                                                               |
| Pitch Bender                                                              | 0                                                                                                                                                 | ×                               | 7 bit RESO                                                                                                    |
| Control 1<br>4<br>7<br>8 - 3<br>64<br>Change' 65<br>66 - 95               | 0<br>0<br>0<br>1 0<br>0<br>0<br>0                                                                                                                 | ×<br>×<br>×<br>×<br>X<br>X<br>X | Modulation<br>Foot Controller<br>Volume<br>Continuous<br>Sustain foot sw<br>Portament sw<br>Switches (on/off) |
| Prog Change : True #                                                      | 0 0 - 127<br>*****                                                                                                                                | X<br>X                          |                                                                                                               |
| System Exclusive                                                          | X                                                                                                                                                 | X                               |                                                                                                               |
| System : Song Pos<br>: Song Sel<br>Common : Tune                          | X<br>×<br>0                                                                                                                                       | X<br>X<br>×                     |                                                                                                               |
| System :Clock<br>Real Time :Commands                                      | X<br>x                                                                                                                                            | X<br>X                          |                                                                                                               |
| Aux. :Local ON/OFF<br>:All Notes OFF<br>Mes- :Active Sense<br>sages:Reset | X<br>0<br>x<br>X                                                                                                                                  | X<br>X<br>X<br>X                |                                                                                                               |
| Notes MIDI EXT<br>Output Jack                                             | The MIDI EXT output jack transmits only Prog Change messages (0-99) when the EXT CONTROL switch is "ON", otherwise works as other MIDI. OUT jacks |                                 |                                                                                                               |

Mode 1 : OMNI ON, POLY  
 Mode 3 : OMNI OFF, POLY

Mode 2 : OMNI ON, MONO  
 Mode 4 : OMNI OFF, MONO

0 : Yes  
 x : no